

BEYOND COLD

OWNER'S GUIDE

Pursuit

Setup • Operation • Maintenance • Warranty

CHILLER BUILT IN TENNESSEE, USA

1 Welcome & Quick Start

Welcome to Beyond Cold

The Pursuit pairs a durable acrylic cold therapy tub with a high-efficiency external chiller for dependable, consistent recovery at home.

Premium Acrylic

Durable construction with a clean, timeless profile.

High-Efficiency Cooling

Designed to cool water down to 37°F.

Quick Domestic Support

Reliable service from our U.S.-based team.

Easy Upkeep

Simple filtration and maintenance for everyday use.

External Chiller

Powerful cooling with easy-access hoses and controls.

5-Step Quick Start

01

**Choose
Location**

02

**Connect
Hoses**

03

**Install
Strainer**

04

Fill Water

05

**Power & Set
Temp**

Recommended first session: 50–55°F for 1–3 minutes.

2 Safety Precautions

Drowning

Never use the tub alone, especially if you're new to cold therapy. Always have someone present who can assist you in case of difficulties.

Hypothermia

Limit cold immersion to 3–5 minutes, or 1–3 minutes if new to cold therapy. Cold exposure longer than recommended can result in hypothermia, which is dangerous and may be fatal.

Shock

Be aware that sudden immersion in cold water may shock your system, especially if you have underlying health conditions.

Alcohol / Drugs

Never use the tub while under the influence of drugs or alcohol.

Consult a Physician

Speak to your healthcare provider before use if you are pregnant, have underlying medical conditions such as circulatory disorders, diabetes, or heart issues, or are under 18 years of age.

Children

Do not allow children to use the tub without consulting a physician or pediatrician. Always supervise children near the tub.

Always use cold therapy responsibly and stop immediately if you feel faint, dizzy, numb, or unwell.

3 Pursuit Tub Overview

The Pursuit Cold Therapy Tub

Designed for optimal cold immersion, the Pursuit combines comfort, durability, and easy maintenance. Its premium acrylic construction and ergonomic shape create a dependable setup for consistent recovery sessions.



Length	73 in	Width	33 in
Height	27 in	Seated Depth	24 in
Weight Empty	148 lb	Weight Full	940 lb
Capacity	95 gal	Warranty	1 Year

4 Controls & Components



Controls

Our user-friendly controller allows you to easily set and monitor your ideal water temperature. Clear display readings and simple adjustments give you precise control over your cold therapy experience.



Power Cable

The GFI-protected power cable includes built-in test and reset buttons plus an indicator light for quick power verification and added safety.

Quick Connects

Secure fittings with stainless steel pins and rings for a precise, lasting fit.

Black Vinyl Tubing

Flexible, algae-resistant tubing helps maintain clean, consistent water flow.

Pre-Strainer

Helps stop debris before it enters the circulation system.

Inlet Nozzle

Promotes proper circulation and visible surface movement when needed.

5 Setting Up the Tub & Chiller

01 Location

Choose a location that can support at least 1,000 lbs. Avoid placing the chiller in areas that cannot get wet. Both the chiller and hoses may create condensation, and water spills are possible.

02 Electrical Connection

Place the chiller close to a 120V 15 amp outlet. Avoid using extension cords. If necessary, use a 12 AWG extension cord with a single tap, not a power strip.

03 Connecting the Chiller

The hoses are color-coded. Match the blue-ring chiller fitting to the blue-ring tub fitting and repeat for red. Push each hose onto the quick-connect, pull the levers toward you to lock, then insert the locking pins.

Match blue to blue and red to red before locking the quick-connect fittings in place.

6 Connecting, Straining & Filling



1. Securely place the pre-strainer into the tub's drain to prevent debris from entering the system.
2. Fill the tub until the water is approximately 2 inches above the inlet.
3. Step into the tub and check the water level. It should sit just above your shoulders when submerged; add water as needed.
4. If the water level is correct but the surface does not ripple, attach the included inlet nozzle to promote proper flow.

Before powering the chiller, confirm the water level is above the inlet and all quick-connects are fully locked.

7 Operating The Chiller

Powering On

Plug in the chiller and turn it on. Check that the power light is illuminated. If not, press the button nearest to the light.

Adjusting the Temperature

Set the controller to your desired temperature. Listen for the chiller to begin priming and make sure no large air bubbles are coming from the inlet jet. Three dashes on the temperature display means the cooling feature is off.

Ensuring Proper Water Flow

Check that water flows continuously from the outlet and ripples the water surface. If flow is weak or absent, verify the water level. If needed, open the quick-connect fitting on the chiller outlet to manually release trapped air.

Beginner

50–55°F

1–3 min

Intermediate

45–50°F

3–5 min

Advanced

37–45°F

Up to 10 min*

***Do not exceed 10 minutes without taking a break.**

8 Using the Cold Plunge Tub

Temperature and Duration:

Beginners should limit sessions to 1–3 minutes. Gradually increase as your body adapts, extending up to 3–5 minutes.

Experienced users can extend immersion time, but do not exceed 10 minutes without taking a break. Prolonged exposure beyond 10–15 minutes can increase the risk of adverse effects, including hypothermia.

Cover: Use the included cover when the tub is not in use to maintain water temperature and prevent debris from entering the tub.

Before

Focus on controlled breathing and enter slowly.

During

Stay aware of how you feel and exit if you become dizzy, faint, numb, or unwell.

After

Exit carefully, hydrate, and allow your body to warm naturally.

9 Maintenance & Winterizing

Water Treatment

Periodically treat the water with chlorine to maintain cleanliness. Chlorine kits are available on our website.

Cleaning the Filter Basket

Clean the filter basket weekly. Turn off the chiller, unscrew the filter basket lid, clean out debris, reinstall it properly, then power the chiller back on and verify proper water flow.

Water Replacement

Replace the water every 2–4 weeks depending on usage and water treatment. Watch for changes in clarity or smell.

Winterizing Your Chiller

If ambient temperatures may drop to freezing, 32°F or below, disconnect, drain, and store the chiller indoors to prevent damage.

1. Unplug the chiller and drain all water from the tub pipes.
2. Remove the jet nozzle from the inlet and install the 3/4-inch threaded plug.
3. Remove the pre-strainer and insert the stopper into the floor drain.
4. Disconnect the hoses from the tub.
5. Tip the chiller to drain all water out.
6. Store the chiller indoors until outdoor temperatures consistently stay above freezing.

The tub may be drained completely, or the plugs may remain in place while the tub is exposed to outdoor ambient temperatures.

10 Troubleshooting & FAQs

1. Should I keep the chiller running all the time?

Yes. Continuous operation keeps the water cold, reduces bacterial growth, and keeps the tub ready to use. Cooling from room temperature can take hours.

2. How often should I clean the filter?

Clean the filter basket every 5–7 days to maintain optimal water flow, clarity, and efficient operation.

3. How do I know if the chiller is primed correctly?

Check for a steady flow from the outlet and a slight ripple on the water surface. If flow is weak, release trapped air from the outlet quick-connect or add water to the filter basket.

4. What if the water isn't cooling?

Confirm the chiller is powered on, the temperature is set, and water flow is strong. Clean the filter basket if needed and contact support if the issue continues.

5. How often should I replace the water?

Replace water every 2–4 weeks depending on usage and treatment. Watch for changes in clarity or smell.

6. Can I use chemicals?

Yes. Use mild treatments such as hydrogen peroxide or chlorine in recommended amounts and avoid harsh chemicals that could damage the tub or chiller.

7. How can I prevent freezing?

If temperatures may reach freezing, 32°F, insulate the tub and chiller. For extreme conditions, bring the chiller indoors or drain the system.

8. Is the cold tub safe for children?

The manual identifies the tub as designed for adults. Consult a physician for anyone's use of cold therapy and have a responsible spotter for new users.

9. How long should I stay in?

Beginners: 1–3 minutes. Experienced users: 3–5 minutes. Avoid exceeding 10 minutes without a break.

10. Is condensation normal?

Yes. Place the tub where water exposure is acceptable and wipe away excess condensation as needed.

11 Warranty & Support

All Beyond Cold chillers and plunge tub packages include a one-year warranty. Select packages may offer an optional extended warranty for an additional fee, based on your specific purchase.

Beyond Cold warrants its products to be free from defects in materials and workmanship beginning on the date of purchase. The limited warranty does not cover damage, deterioration, or malfunction caused by alteration, modification, improper or unreasonable use or maintenance, misuse, abuse, accident, neglect, excess moisture, fire, improper packing or shipping, lightning, power surges, or other acts of nature.

Beyond Cold's warranty liability is limited to the replacement cost of the product. Beyond Cold will, at its discretion, repair or replace any covered chiller or package component. To request warranty service, contact technical support at **support@beyondcold.com**.

Shipping and Handling for Warranty Repairs: The customer is responsible for shipping charges to send the product to Beyond Cold, proper packaging, insurance, and the risk of loss or damage during shipment. Once received, Beyond Cold will repair or replace the product at its discretion and cover return shipping within the continental 48 states. Additional surcharges may apply outside the continental 48 states.

Warranty Disclaimer: TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS LIMITED WARRANTY AND THE REMEDIES SET FORTH HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES, AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED.

Need Help?

Our Tennessee-based team is here to help with product questions, setup, maintenance, and technical support.

Call: 865.450.8323

Email: info@beyondcold.com

Address: 1157 Corridor Park Blvd, Knoxville, TN 37932

Website: beyondcold.com/contact